## Appendix 5 Example Risk Assessment for Small Scale Use of Hydrogen Supplied by a Gas Cylinder for an Experiment

Title:		Assessed By:	Date of Assessment:			
Step 1 What are the hazards?	Step 2 Who might be harmed and how?	What are you already doing?	Step 3: What further action is necessary?	Step 4: How will you put the Assessment into action?		
Hazard/Task or Situation				Action by whom	By when	Done
H2 cylinder store and supply pipes. Creation of a flammable atmosphere in the vicinity of the H2 cylinder store due to external ignition sources or electrostatic ignition risks leading to localised flash fire outside or localised flame / pressure effects inside in the vicinity of H2 pipework	Building regularly occupied by one member of staff Infrequent occupancy outside Operator Persons in vicinity	Well ventilated outdoor location.  Fixed, secure Swagelok pipework  Storage facility designed to BCGA CP4  Pipework designed to BGCA CP33  Warning signs displayed  Leak testing of pipework following intrusive maintenance.  Preventative maintenance and	Fit guarding to protect against impact damage from vehicles  Install H2 gas detection in the building and automatic shut off outside laboratory. Set detection to as low as practical e.g. 5% of LFL			

Author Jane Vickers Issue	No: 1 Issue Date: 17/11/200	Page 39 of 43
---------------------------	-----------------------------	---------------

Creation of a flammable atmosphere within	Low occupancy but no formal controls. Operators	inspection on pipework particularly cylinder connections and hoses  No smoking rules  High integrity pipework designed to BGCA CP33	Check the sensitivity and accuracy of the low air extract flow switch –		
air extraction around H2 equipment including exhaust duct. Possible external ignition sources from electrical equipment, electrostatic ignition sources and mechanical ignition from air exhaust fan	Persons in vicinity	Leak testing of pipework following intrusive maintenance.  Remainder of pipework and experimental equipment operate at very low pressure which limits leakage  Flow control limits the H2 exhaust	confirm detectors are set as close to design air flows as possible.  Carry out routine testing ion switch  Consider automated shut off of H2 on low extract airflow		
mom all oxilador lan		H2 shut off on loss of extract flow (operator emergency procedure)	Consider installing H2 gas detection in exhaust duct and automatic H2 shut off. Set detection as low as practicable e.g. 10% of LFL		
Step 5 Review Date:	l		Du are still improving, or at least not sliding barkplace, remember to check your risk assessr	essary, amend	it.

Author Jane Vickers Issue No: 1	Issue Date: 17/11/2008	Page 40 of 43
---------------------------------	------------------------	---------------